



**HIGH PERFORMANCE  
STAINLESS STEEL EXHAUSTS**

## SCHEMA DI MONTAGGIO - ASSEMBLY SCHEDULE

COD. **58.0546.00**

REV. **00**

DEL. **19/07/2012**

TEC-LOG **G.D.**

Descrizione **BMW X3 (typ F25)**

**Fig. 1**

- Montare le staffe in dotazione come nelle tre immagini;
- Install the bracket in equipment as shown in the three pictures;
- Installer l'étrier en dotation comme montré dans les trois images;
- Montar el estribo en dotación, como en las tres imágenes;
- Installieren Sie die Schelle des Montagekits wie in den 3 Bildern gezeigt;



**Fig. 2**

- Utilizzare il gommino originale della staffa centrale prevista sullo scarico di serie;
- Use the original gum-ring of the central bracket of the original exhaust system;
- Utilisant le petit bouchon en caoutchouc de l'étrier central de l'échappement d'origine;
- Utilizar el anillo de goma original del estribo central, que se encuentra en el escape de serie;
- Benutzen Sie den Serien-Gummiring der zentralen Halterung der Serien-Anlage;








**Fig. 3**





**HIGH PERFORMANCE  
STAINLESS STEEL EXHAUSTS**

**Fig. 4**

-  Tagliare la nicchia sul lato destro simmetricamente a quella originale!
-  Incise the niche on the right side symmetrically to the original ones!
-  Entailler la niche à droite en symétrie à la niche originale!
-  Entallar el agujero en el lado derecho en simetria con el original!
-  Schneiden Sie die Niche auf der rechten Seite symmetrisch zu der Originalen ein!



**Fig. 5**



**Fig. 6**

**Fig. 7**