

SCHEMA DI MONTAGGIO - ASSEMBLY SCHEDULE

COD. **53.0097.00**

REV. **00** DEL. **05/04/2023** TEC-LOG **G.Dalto**

Descrizione **Alfa Romeo Tonale**

Fig. 1



Fig. 2






-  Togliere le mascherine originali.
-  Remove the original masks indicated in the picture.
-  Retirez les masques d'origine indiqués sur l'image.
-  Quitar las mascarillas originales.
-  Entfernen Sie die im Bild angezeigten Originalmasken.



Fig. 3






-  Inserire le nuove mascherine con il foro.
-  Insert the new masks with the hole
-  Insérez les nouveaux masques avec le trou.
-  Insertar las nuevas mascarillas con el agujero.
-  Setzen Sie die neuen Masken mit dem Loch ein.



Fig. 4



Fig. 5











-  Infine installare lo scarico.
-  Install the exhaust.
-  Monter l'échappement.
-  Por último, instalar el escape.
-  Montieren Sie den Auspuff.



Fig. 6



Fig. 7

-  Mascherine adatte per terminali rotondi $\varnothing 102\text{mm}$ / $\varnothing 100\text{mm}$.
-  Masks suitable for $\varnothing 102\text{mm}$ / $\varnothing 100\text{mm}$ round tail pipe.
-  Masques adaptés aux sorties rondes $\varnothing 102\text{mm}$ / $\varnothing 100\text{mm}$.
-  Mascarillas aptas para salidas redonda $\varnothing 102\text{mm}$ / $\varnothing 100\text{mm}$.
-  Masken geeignet für runde Endrohre $\varnothing 102\text{mm}$ / $\varnothing 100\text{mm}$.